

# INSTALLATION AND USER MANUAL

## TOWEL DRYER



## **1. Connection**

- *Power supply: 230V/50Hz.*
- *Rating: IP44*
- *Protection class I*
- *Wattage 100W*
- *The towel dryer can be installed in zone 2 in the bathroom; the connection socket must be located in zone 3 and must be connected via a residual-current circuit breaker with a conventional operating current of  $I_{\Delta n} \leq 30\text{mA}$ .*
- *Thermal fuse*
- *Connection of the product to the mains must comply with general safety requirements as well as technical standards for the connection of electric appliances. The installed plug has a lower IP rating than the product; its removal doesn't void the warranty.*

## **2. Usage**

- *for the drying of towels, hand towels and dish towels*

## **3. Installation**


- *The towel dryer is ready for connection to the mains; it doesn't need to be adapted additionally*
- *The towel dryer must be installed in a vertical position with the outlet facing downwards.*
- *If the supply cable of the appliance is damaged, it must be replaced by the manufacturer or their service technician, or by a person with similar qualifications.*

### **Procedure:**

- *Attach the radiator according to the diagrams on the following page.*

## **4. IMPORTANT SAFETY MEASURES**


- *Please read the whole instruction manual before using the heater.*
- *This appliance isn't intended for use by people (including children) whose physical, sensory or mental inability or lack of experience prevents them from using the appliance safely unless they are supervised or have been instructed regarding the use of the appliance by a person responsible for their safety.*
- *Children should be supervised in order to ensure that they do not play with the appliance.*
- *Always unplug the heater from the socket when you are not using it; the heater will be disconnected by taking the plug out of the socket.*
- *Never use the heater if its lead or plug is damaged. The same applies if the heater is not functioning properly, if it has fallen down or has been damaged in some way.*
- *Do not use the heater outdoors.*
- *Never place the heater where there is a danger of it falling into the bath or other vessels containing water.*
- *Do not use the heater in areas where there are flammable liquids.*
- *Only use this heater as described in this instruction manual. Any other use which has not been recommended by the manufacturer can result in fire, injury from electric current or injury to people.*
- *Please keep this instruction manual for later use.*




**Step 1**  
Mark the locations for holes on the wall



**Step 2**  
Drill the holes into the wall.



**Step 3**  
Insert the wall plugs for the screws into the openings.



**Step 4**  
Position the hooks for hanging and install them on the wall using screws.

#### **4. Warranty**

*A warranty of 24 months after the date of purchase is provided for this product. The warranty applies to material flaws and defects which occurred during manufacture of the appliance. The warranty is not valid in the case of faults caused by non-expert adjustments, carelessness, incorrect use, or defects caused during transport or inappropriate storage.*

*Type of product:*

*Date:*

*Stamp, signature:*



**Fenix Trading s.r.o.**

Slezská 2, 790 01 Jeseník

tel.: +420 584 495 304, fax: +420 584 495 303

e-mail: [fenix@fenixgroup.cz](mailto:fenix@fenixgroup.cz) , <http://www.fenixgroup.cz>